

# **Gumax® Lighting System Remote**



# Control each light element separately

We recommend linking each light element to its own numerical button (1 to 8). This allows you to easily control each light element separately. Do you have more than 8 light elements? Then pair several light elements with the same numerical button. The assembly instructions tell you how to connect the light elements to the numerical buttons.

#### Set your favourite scenes

- Set the desired colour and brightness for each light element. It is also possible to leave certain light elements off or give them a different brightness.
- Press and hold the S button in combination with one of the eight numerical buttons for a longer time until the indicator light on the remote control stops flashing.
- Your desired scene is now set. All programmed scenes can be selected using the S- and S+ buttons or by briefly pressing the S button in combination with a numerical button.
- Want to replace an old scene with a new one? Then follow the same steps.

# Set warm to cool-white light

Briefly press the W button repeatedly to adjust from warm to cool-white light.

#### Use the Multi-colour mode

- First press = red light
- Second press = green light
- Third press = blue light
- Fourth press = automatic colour change

#### Remote control with a memory

The remote remembers where you left off. If you perform another action in between, the remote control will pick up the setting where you left off.

### Adjust the colour & brightness to your liking

First, select the light element(s) you want to control. You can then use the colour wheel to adjust the colour or change the brightness. This rule also applies when using a programmed scene.